# HANGERS





# **Table of contents**

APC 1	12.2	LIBRA H7 DOWEL FIXING WITH "PEG JOINT" FOR ALUMINIUM BAR	12.42
APC 3	12.4	LIBRA H7 COVER CAPS	12.54
APC 4	12.6	LIBRA H11	12.58
APC 6	12.9	LIBRA H11 COVER CAP	12.63
LIBRA H1	12.14	LIBRA WALL PLATES	12.64
LIBRA H2	12.16	LIBRA COVER CAPS	12.67
LIBRA H3	12.19	LIBRA BS	12.71
LIBRA H4	12.22	LIBRA BS LEVELLER	12.77
LIBRA H6	12.26	SH1 ANTI-TIP BRACKET	12.82
LIBRA CH	12.32	SH7 ANTI-TIP BRACKET	12.84
LIBRA H7 SCREW FIXING	12.38	LIKU	12.87

# Index of applications

### HANGERS FOR WALL UNITS

- ► APC 1
- ► APC 3
- ► APC 4
- ► APC 6
- LIBRA H1
- LIBRA H2
- LIBRA H3
- LIBRA H4
- HANGERS FOR BASE UNITS
- LIBRA H6
- ► LIBRA CH

▶ LIBRA H7





# HANGERS FOR LIBRARIES

ANTI-TIP BRACKETS

LIKU

► SH1

► SH7



LIBRA H11



LIBRA BS



# APC 1, APC 3, APC 4, APC 6 LIVING SETTINGS




APC 1




APC 3

APC 6





INSTALLATION UNDER THE CABINET TOP





countersunk head wood screws Ø3,5x20 mm



Certificates available on request.

COVER CAP INSERTING



INSTALLATION ON THE WALL






It is the responsibility of the customer:


to ensure that the wall is of a suitable quality to hold the unit fixing in place.to use the proper hardware fittings according to the construction of the wall.

For more specific information, please refer to the WARNINGS section at the end of the catalogue.

#### ADJUSTMENTS










#### DRILLING PLAN FOR APC 1 FIXED UNDER THE CABINET TOP

#### SIDE PANEL AND SERVICE GAP




















# **APC 1 FIXING ACCESSORY**












INSTALLATION UNDER THE CABINET TOP



countersunk head wood screws Ø3,5x20 mm

Pre-inserted plastic clip with screw Ø 4x25 mm - PZ2


> Without plastic clip. Recommended fixing countersunk head wood screw Ø 3,5x20 mm



#### INSTALLATION ON THE WALL








70 Kg per piece

It is the responsibility of the customer:


- to ensure that the wall is of a suitable quality to hold the unit fixing in place.

- to use the proper hardware fittings according to the construction of the wall.

#### ADJUSTMENTS









12

Ð 12.4


#### DRILLING PLAN FOR APC 3 FIXED UNDER THE CABINET TOP

#### SIDE PANEL AND SERVICE GAP







BACK PANEL









15,2






# **APC 3 FIXING ACCESSORY**








APC 4



INSTALLATION





recommended fixing countersunk head wood screws Ø 3,5x20 mm




Certificates available on request.

COVER CAP INSERTING

k

INSTALLATION ON THE WALL







It is the responsibility of the customer:


- to ensure that the wall is of a suitable quality to hold the unit fixing in place.

- to use the proper hardware fittings according to the construction of the wall.

#### ADJUSTMENTS







12

12.6


#### DRILLING PLAN FOR APC 4 FIXED UNDER THE CABINET TOP


#### SIDE PANEL AND SERVICE GAP

#### BACK PANEL


#### APC cover cap <mark>Ø20</mark>


#### APC cover cap double hole $\emptyset12$





16 min.

















# **APC 4 FIXING ACCESSORY**



## APC 6




INSTALLATION UNDER THE CABINET TOP





countersunk head wood screws Ø3x40 mm




Certificates available on request.

COVER CAP INSERTING

INSTALLATION ON THE WALL







It is the responsibility of the customer:


to ensure that the wall is of a suitable quality to hold the unit fixing in place.to use the proper hardware fittings according to the construction of the wall.

For more specific information, please refer to the WARNINGS section at the end of the catalogue.

#### ADJUSTMENTS









#### DRILLING PLAN FOR APC 6 FIXED UNDER THE CABINET TOP

#### SIDE PANEL AND SERVICE GAP

16 min.



BACK PANEL




13,5














# **APC 6 FIXING ACCESSORY**




























WPC3 WALL BAR Certificates available on request.













# APC COVER CAP Ø20





# APC COVER CAP DOUBLE HOLE Ø12





# LIBRA H1 - H2 - H3 - H4 LIVING SETTINGS



LIBRA H1

LIBRA H3




LIBRA H2

LIBRA H4

### LIBRA H1




INSTALLATION UNDER THE CABINET TOP



#### INSTALLATION ON THE WALL

- For details refer to "LIBRA WALL PLATES"



It is the responsibility of the customer:

- to ensure that the wall is of a suitable quality to hold the unit fixing in place. - to use the proper hardware fittings according to the construction of the wall.

For more specific information, please refer to the WARNINGS section at the end of the catalogue.


#### ADJUSTMENTS









1 VERTICAL ADJUSTMENT




2

IN-DEPTH ADJUSTMENT





3 ANTI-TURNOVER LOCKING Stop screwing the red bolt when it touches the wall plate








EN 15939:2019 - 65 Kg per piece



PATENTED Certificates available on request.

#### ALTERNATIVE INSTALLATION



#### COVER CAP INSERTING

- For details refer to "LIBRA COVER CAPS"

Back to table of contents


12.14 Ħ


#### DRILLING PLAN FOR LIBRA H1 FIXED UNDER THE CABINET TOP


#### SIDE PANEL AND SERVICE GAP

#### Libra CC1-CC4-CC5 cover cap

BACK PANEL








Libra CC2 cover cap











NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.

# LIBRA H1 FIXING ACCESSORY








### LIBRA H2





INSTALLATION UNDER THE CABINET TOP



#### INSTALLATION ON THE WALL

- For details refer to "LIBRA WALL PLATES"







2




VERTICAL ADJUSTMENT

13 mm

For more specific information, please refer to the WARNINGS section at the end of the catalogue.








UNI 68840:2004 - 75 Kg per piece

PATENTED Certificates available on request.


#### ALTERNATIVE INSTALLATION




recommended fixing countersunk head wood screws Ø 3,5x20 mm

#### COVER CAP INSERTING

- For details refer to "LIBRA COVER CAPS"



3 ANTI-TURNOVER LOCKING Stop screwing the red bolt when it touches the wall plate



Back to table of contents


#### DRILLING PLAN FOR LIBRA H2 FIXED UNDER THE CABINET TOP


#### SIDE PANEL AND SERVICE GAP

# BACK PANEL


### Libra CC1-CC4-CC5 cover cap

# 





Libra CC2 cover cap










NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.

### LIBRA H2 WITHOUT ROTARY LEVER

#### DRILLING PLAN FOR LIBRA H2 FIXED UNDER THE CABINET TOP

#### SIDE PANEL AND SERVICE GAP



15


22,5

142


37

32


32




0








NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.



Ø3,5 20 Ø7

**LIBRA H2 FIXING ACCESSORY** 





12.18

### LIBRA H3



#### INSTALLATION UNDER THE CABINET TOP





Pre-inserted plastic clip with screw Ø 4x25 mm - PZ2




Without plastic clip. Recommended fixing countersunk head wood screw Ø 3,5x20 mm




recommended fixing countersunk head wood screw Ø 3,5x20 mm

#### INSTALLATION ON THE WALL

- For details refer to "LIBRA WALL PLATES"






It is the responsibility of the customer:

- to ensure that the wall is of a suitable quality to hold the unit fixing in place.

- to use the proper hardware fittings according to the construction of the wall.

For more specific information, please refer to the WARNINGS section at the end of the catalogue.








UNI 68840:2004 - 70 Kg per piece




PATENTED Certificates available on request.





#### COVER CAP INSERTING

- For details refer to "LIBRA COVER CAPS"





12

2

12 mm

#### DRILLING PLAN FOR LIBRA H3 FIXED UNDER THE CABINET TOP

29

SIDE PANEL AND SERVICE GAP


40

11

BACK PANEL

#### Libra CC1-CC4-CC5 cover cap


Libra CC2 cover cap



15

22,5

147,5



40

11




(44)


(24)


Ø30






NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.











NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.

# LIBRA H3 FIXING ACCESSORY








## LIBRA H4



INSTALLATION






2

12 mm

recommended fixing countersunk head wood screws Ø 3,5x20 mm

#### INSTALLATION ON THE WALL

- For details refer to "LIBRA WALL PLATES"



It is the responsibility of the customer:

- to ensure that the wall is of a suitable quality to hold the unit fixing in place.


- to use the proper hardware fittings according to the construction of the wall.

For more specific information, please refer to the WARNINGS section at the end of the catalogue.






- For details refer to "LIBRA COVER CAPS"



3 ANTI-TURNOVER LOCKING Stop screwing the red bolt when it touches the wall plate







80 Kg per piece


#### DRILLING PLAN FOR LIBRA H4 FIXED BEHIND THE CABINET TOP

#### SIDE PANEL AND SERVICE GAP

BACK PANEL


Libra CC1-CC4-CC5 cover cap

Libra CC2 cover cap




NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.

# LIBRA H4 FIXING ACCESSORY








Back to table of contents

# LIBRA H6 LIVING SETTINGS






WALL CABINET APPLICATION

- Capacity loading 120 Kilos per piece (240 Kilos per pair).In accordance with the European Regulation DIN 68840.

### LIBRA H6





INSTALLATION UNDER THE CABINET TOP



#### INSTALLATION ON THE WALL


- For details refer to "LIBRA WALL PLATES: LIBRA WP5 "





COVER CAP INSERTING

- For details refer to "LIBRA COVER CAPS"



It is the responsibility of the customer:


- to ensure that the wall is of a suitable quality to hold the unit fixing in place.
- to use the proper hardware fittings according to the construction of the wall.
- For more specific information, please refer to the WARNINGS section at the end of the catalogue.

















2


3 ANTI-TURNOVER LOCKING Stop screwing the red bolt when



PATENTED

Back to table of contents

#### DRILLING PLAN FOR LIBRA H6 SIDE PANEL AND SERVICE GAP




Libra CC1-CC4-CC5 cover cap Libra CC2 cover cap 16 min.\*\* 16 min.\*\* 18 18 Ξ Ξ (26) 54,5 (24) 54 -G -0 -0 -0-Ø30 12

**BACK PANEL** 


\* Our technical department is at your disposal for different service gap options. \*\* For side panel 15 mm thick use "Libra H6 SPACER - 1 mm".















NOTE: for technical details about wall plates and cover caps please refer to the related sections "LIBRA WALL PLATES" on page 12.65 and "LIBRA COVER CAPS" on page 12.68.

# LIBRA H6 SPACER - 1 mm



# LIBRA H6 FIXING ACCESSORY



# LIBRA H6 and LIBRA CH LIVING SETTINGS









LIBRA CH

### LIBRA H6 and LIBRA CH APPLICATIONS

#### BENEFITS OF LIBRA H6 AND LIBRA CH HANGING SYSTEMS:

- Vertical and in-depth adjustments, as well as the locking of the cabinet, can be easily and smoothly carried out from the inside.

- The hanging system is never interfering with the slides for drawers as it is placed behind the back panel.

- Absolutely no mills, drillings or grooves required inside the cabinet.

In the current absence of a unifying European norm which sets the standards for testing procedures aimed at defining capacity loadings of hanging systems conceived for suspended base units, we Italiana Ferramenta have simulated some of the most critical scenarios.

The following simulations are meant to give our customers valid reference points concerning cabinet dimensions, weights, recommended loading capacity even when loaded drawers are opened.

The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate. The customer must ensure that the wall is of suitable quality and structure.

Other important factors to be taken into consideration are determined by:

- the type of side panel, the actual thickness and the material used. It is recommended to use chipboard panels. For MDF panels please contact us for further information concerning the screw fixing.


- the type and dimensions of the screws used.


- the actual positioning, depth and width of the groove milled for the back side installation.


- the capacity loading of the drawer slides used as well as the actual construction of the drawer.

We always recommend to test a complete cabinet.

#### For cases which differ from the ones reported, please contact us.







FURNITURE			
FURNITURE TYPE	LIBRA H6	LIBRA H6 + 1 LIBRA CH	
Cabinet	100 Kg	150 Kg	
Cabinet + drawer	70 Kg + 30 Kg	120 Kg + 30 Kg	


<b>EUDNITUDE</b>			
FURNITURE TYPE	LIBRA H6	LIBRA H6 + 1 LIBRA CH	
Cabinet	180 Kg	230 Kg	
Cabinet + drawer	150 Kg + 30 Kg	180 Kg + 50 Kg	

FURNITURE TYPE	LIBRA H6	LIBRA H6 + 1 LIBRA CH	
Cabinet	200 Kg	230 Kg	
Cabinet + drawer	170 Kg + 30 Kg	170 Kg + 50 Kg	


The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate.

LIBRA H6

#### LIBRA CH



# DEMONSTRATION SCHEME : WHERE AND HOW TO USE LIBRA H6 AND LIBRA CH




### **LIBRA CH**




#### APPLICATION

LIBRA CH to be cut on size flushing with both top and bottom panels.



#### ADJUSTMENTS Slots for cross PZ2 screwdriver

1 - VERTICAL ADJUSTMENT LIBRA H1-H2-H3-H6-H7 - 13 mm









It is the responsibility of the customer: - to ensure that the wall is of a suitable quality to hold the unit fixing in place.

- to use the proper hardware fittings according to the construction of the wall.


For more specific information, please refer to the WARNINGS section at the end of the catalogue.

vertical adjustment carried

LIBRA H1-H2-H3-H6-H7


LIBRA CH

LIBRA H1-H2-H3-H6-H7




LIBRA CH Back to table of contents






#### The present groove has to match the groove required by the cabinet hanger used.





Drilling plan for the matching with LIBRA H2


Drilling plan for the matching with LIBRA H3

Drilling plan for the matching with LIBRA H6 - H7











#### LIBRA CH WITH BOTH UPPER AND LOWER END ELEMENTS PRE-MOUNTED




 ${\bf L}=$  Total CH including both upper and lower elements.


### LIBRA CH FIXING ACCESSORY







# LIBRA CH WITH UPPER END ELEMENT PRE-MOUNTED (SEPARATE LOWER END ELEMENT)



## LIBRA H7 APPLICATIONS: SCREW FIXING and DOWEL FIXING WITH OPTIONAL ALUMINIUM BARS

#### BENEFITS OF LIBRA H7 HANGING SYSTEM:

- Vertical and in-depth adjustments as well as the locking of the cabinet, can be easily and smoothly carried out from the inside.
- The hanging system is never interfering with the slides for drawers thanks to the slim side bracket wings.
- Absolutely no mills, nor grooves required on the side panels.


In the current absence of a unifying European norm which sets the standards for testing procedures aimed at defining capacity loadings of hanging systems conceived for suspended base units, we Italiana Ferramenta have simulated some of the most critical scenarios. The following simulations are meant to give our customers valid reference points concerning cabinet dimensions, weights, recommended loading capacity even when loaded drawers are opened.

The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate. The customer must ensure that the wall is of suitable quality and structure.


- Other important factors to be taken into consideration are determined by:
- the type of side panel, the actual thickness and the material used.
- the type and dimensions of the screws used.
- the actual positioning, depth and width of the groove milled for the back side installation.
- the capacity loading of the drawer slides used as well as the actual construction of the drawer.

We always recommend to test a complete cabinet.

#### For cases which differ from the ones reported, please contact us.




The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate.




LIBRA H7 AND CABINET WITH STRUCTURAL TOP		FURNITURE TYPE	LIBRA H7 DOWEL FIXING AND ALU BAR H 40,2 WITH 2 EXTR/	
SCREW FIXING	DOWEL FIXING		HANGING POINTS	
160 Kg	150 Kg	Cabinet	180 Kg	
120 Kg + 30 Kg	110 Kg + 30 Kg	Cabinet + drawer	140 Kg + 30 Kg	

The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate.



LIBRA H7 AND CABINET WITH STRUCTURAL TOP		FURNITURE TYPE	LIBRA H7 DOWEL FIXING AND ALU BAR H 40,2 WITH 2 EXTRA	
SCREW FIXING	DOWEL FIXING		HANGING POINTS	
200 Kg	170 Kg	Cabinet	210 Kg	
130 Kg + 60 Kg	100 Kg + 60 Kg	Cabinet + drawer	140 Kg + 2 x 30 Kg	


The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate.




LIBRA H7 AND CABINET WITH STRUCTURAL TOP		FURNITURE TYPE	LIBRA H7 DOWEL FIXING AND ALU BAR H 40,2 WITH 2 EXTRA	
SCREW FIXING	DOWEL FIXING		HANGING POINTS	
200 Kg	170 Kg	Cabinet	210 Kg	
160 Kg + 30 Kg	130 Kg + 30 Kg	Cabinet + drawer	170 Kg + 30 Kg	


The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate.

The hanging system is never interfering with the slides for drawers thanks to the slim side bracket wings.





#### Easy access to the adjustments




The slim side bracket makes the use of tools very easy and comfortable as there is plenty of space between the side and the screwdriver.

#### = STRESS INTENSITY LEVEL ON THE WALL

By adding extra hanging points on the aluminium bar, the capacity loading is more evenly distributed, thus sensibly reducing the stress intensity level on the wall.





# LIBRA H7 SCREW FIXING LIVING SETTINGS






## LIBRA H7 SCREW FIXING







INSTALLATION UNDER THE CABINET TOP



Recommended fixing flat head screws M6 x 12 mm

#### ALTERNATIVE APPLICATION WITHOUT TOP

INSTALLATION ON THE WALL - For details refer to "LIBRA WALL PLATES: LIBRA WP5"



ADJUSTMENTS





1 VERTICAL ADJUSTMENT 13 mm



It is the responsibility of the customer: - to ensure that the wall is of a suitable quality to hold the unit fixing in place. - to use the proper hardware fittings according to the construction of the wall. For more specific information, please refer to the WARNINGS section at the end of the catalogue.


**2** IN-DEPTH ADJUSTMENT 12 mm **3** ANTI-TURNOVER LOCKING Stop screwing the red bolt when it touches the wall plate






Back to table of contents


#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 - 14 MM



#### DRILLING PLAN WITHOUT BACK PANEL

















NOTE: for technical details about wall plates please refer to the related sections "LIBRA WALL PLATES" on page 12.65.

# LIBRA H7 SCREW FIXING ACCESSORIES















# LIBRA H7 DOWEL FIXING WITH ALUMINIUM BAR LIVING SETTINGS




# LIBRA H7 DOWEL FIXING WITH "PEG JOINT" FOR ALUMINIUM BAR




#### INSTALLATION ON THE WALL

- For details refer to "LIBRA WALL PLATES: LIBRA WP5"




#### ADJUSTMENTS (STEP 1)



#### EXTRA HANGING POINTS (STEP 2)


The pre-drilled pilot holes ease the drilling operations on the wall. Extra hanging points reduce the loading stress on the left/right wall plates.




HANGERS


#### SIDE PANEL 15 MIN

DRILLING PLAN WITHOUT BACK PANEL







#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 MM



#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 MM AND H. 40,2 MM ALUMINIUM BAR





#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 8 MM AND H. 40,2 MM ALUMINIUM BAR




Back to table of contents


#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 MM AND H. 80,5 MM ALUMINIUM BAR












NOTE: for technical details about wall plates please refer to the related sections "LIBRA WALL PLATES" on page 12.65.

# LIBRA H7 ALUMINIUM BAR H. 40,2

#### TO BE CUT BY THE CUSTOMER



Optional pre-drilling operation/s to be carried out by the customer.




# LIBRA H7 ALUMINIUM BAR H. 80,5

TO BE CUT BY THE CUSTOMER



Optional pre-drilling operation/s to be carried out by the customer.




# LIBRA H7 ALUMINIUM BAR H. 40,2 AND H. 80,5 WITHOUT END ELEMENTS

#### TO BE CUT BY THE CUSTOMER

SUGGESTED POSITIONING OF PRE-DRILLED Ø 8 OR Ø 10 INTERMEDIATE PILOT HOLES ACCORDING TO CABINET WIDTH

L1 = L in mm minus 72		
	SUGGESTED CO	
	CABINET WIDTH (mm)	INTERMEDIATE PILOT HOLES
L in mm	up to 450	-
	from 451 to 600	1
	from 601 to 950	2
	from 951 to 1200	3
	over 1201	4
 Side panel thickness		
Cabinet width	_	


#### Cabinet width over 1201



#### CABINET WIDTH OVER 1201

SIDE PANEL	L1
15	1099
16	1097
18	1093
19	1091

#### Cabinet width from 951 to 1200



#### CABINET WIDTH from 951 to 1200

SIDE PANEL	FROM - TO
15	849 - 1098
16	847 - 1096
18	843 - 1092
19	841 - 1090

CABINET WIDTH from 601 to 950

FROM - TO

499 - 848

497 - 846

493 - 842

491 - 840

SIDE PANEL


15

16

18

19

#### Cabinet width from 601 to 950



#### Cabinet width from 451 to 600

# L1 from 349 to 498


#### Cabinet width 450

#### CABINET WIDTH from 451 to 600


SIDE PANEL	FROM - TO
15	349 - 498
16	347 - 496
18	343 - 492
19	341 - 490

#### CABINET WIDTH 450

SIDE PANEL	L1
15	348
16	346
18	342
19	340



## LIBRA H7 ALUMINIUM BAR H. 40,2 WITHOUT END ELEMENTS: CUT ON SIZE WITH PRE-DRILLED Ø 8 INTERMEDIATE PILOT HOLES




### LIBRA H7 ALUMINIUM BAR H. 80,5 WITHOUT END ELEMENTS: CUT ON SIZE WITH PRE-DRILLED Ø 8 INTERMEDIATE PILOT HOLES

 • • • • • • •	0.0.0			
L in mm minus 72		671XX	in mm minus 72	)
		0 = without intermed 1 = with 1 intermedi 2 = with 2 intermedi 3 = with 3 intermedi 4 = with 4 intermedi	ate pilot hole ate pilot holes ate pilot holes	
L in mm	-		MBINATIONS:	
		CABINET WIDTH (mm)	INTERMEDIATE PILOT HOLES	
		up to 450	-	
		from 451 to 600	1	
		from 601 to 950	2	
		from 951 to 1200	3	
		over 1201	4	
 Side panel thickness				
 Cabinet width				

# LIBRA H7 DOWEL FIXING ACCESSORY



# LIBRA H7 H. 40,2 AND H. 80,5 ALUMINIUM BAR FIXING ACCESSORY



# LIBRA H7 H. 80,5 ALUMINIUM BAR FIXING ACCESSORY




## **OPTIONAL VERSION**


# LIBRA H7 SCREW FIXING WITH "PEG JOINT" FOR ALUMINIUM BAR

Certificates available on request.











NOTE: for technical details about wall plates please refer to the related sections "LIBRA WALL PLATES" on page 12.65.


#### SIDE PANEL 15 - 16 MM THICK




SIDE PANEL 18 - 19 MM THICK




#### DRILLING PLAN WITHOUT BACK PANEL




DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 MM




#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 MM AND H. 40,2 MM ALUMINIUM BAR



#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 8 MM AND H. 40,2 MM ALUMINIUM BAR




#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 MM AND H. 80,5 MM ALUMINIUM BAR




## **OPTIONAL VERSION**

# LIBRA H7 DOWEL FIXING WITHOUT "PEG JOINT"









 $\overrightarrow{PZ} = PZZ$   $\overrightarrow{ZA} \quad \overrightarrow{ST} \qquad \overrightarrow{PS} = 50 \text{ pcs.}$   $\overrightarrow{OS} = 50 \text{ pcs.}$ 

NOTE: for technical details about wall plates please refer to the related sections "LIBRA WALL PLATES" on page 12.65.


#### SIDE PANEL 15 MIN






DRILLING PLAN WITHOUT BACK PANEL

#### DRILLING PLAN WITH BACK PANEL WOOD THICKNESS 4 - 14 MM




# LIBRA H7 COVER CAPS LIBRA H7 INTEGRAL COVER

INSTALLATION



## **COVER CAP FOR LIBRA H7 ADJUSTMENTS**

INSTALLATION



# LIBRA H7 and LIBRA CH LIVING SETTINGS









LIBRA CH

## LIBRA H7 and LIBRA CH APPLICATIONS

#### BENEFITS OF LIBRA H7 AND LIBRA CH HANGING SYSTEMS:

- Vertical and in-depth adjustments, as well as the locking of the cabinet, can be easily and smoothly carried out from the inside.

- The hanging system is never interfering with the slides for drawers thanks to the slim side bracket wings.

- Absolutely no mills or grooves required on the side panels.

In the current absence of a unifying European norm which sets the standards for testing procedures aimed at defining capacity loadings of hanging systems conceived for suspended base units, we Italiana Ferramenta have simulated some of the most critical scenarios.

The following simulations are meant to give our customers valid reference points concerning cabinet dimensions, weights, recommended loading capacity even when loaded drawers are opened.


The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate. The customer must ensure that the wall is of suitable quality and structure.


- Other important factors to be taken into consideration are determined by:
- the type of side panel, the actual thickness and the material used concerning the screw fixing.
- the type and dimensions of the screws used.

200

- the actual positioning, depth and width of the groove milled for the back side installation.
- the capacity loading of the drawer slides used as well as the actual construction of the drawer.
- We always recommend to test a complete cabinet.

#### For cases which differ from the ones reported, please contact us.






FURNITURE TYPE	LIBRA H7	LIBRA H7 + 1 LIBRA CH	
Cabinet	120 Kg	130 Kg	
Cabinet + drawer	80 Kg + 30 Kg	120 Kg + 30 Kg	

FURNITURE TYPE	LIBRA H7	LIBRA H7 + 1 LIBRA CH	
Cabinet	180 Kg	230 Kg	
Cabinet + drawer	150 Kg + 30 Kg	180 Kg + 30 Kg	

FURNITURE			
FURNITURE TYPE	LIBRA H7	LIBRA H7 + 1 LIBRA CH	
Cabinet	200 Kg	230 Kg	
Cabinet + drawer	170 Kg + 30 Kg	170 Kg + 50 Kg	

The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled by using WP5 wall plate.




- LIBRA H7 SCREW FIXING (to be used without aluminium bar)

- LIBRA H7 DOWEL FIXING (to be used without aluminium bar). - LIBRA CH

12

distributed, thus sensibly reducing the stress intensity level on the wall.

# DEMONSTRATION SCHEME : WHERE AND HOW TO USE LIBRA H7 AND LIBRA CH



# HANGERS

# LIBRA H11



PATENTED







## LIBRA H11





#### LIBRA H11 SCREW FIXING INSTALLATION



#### INSTALLATION ON THE WALL

- For details refer to "LIBRA WALL PLATES: LIBRA WP13".






- It is the responsibility of the customer:
- to ensure that the wall is of a suitable quality to hold the unit fixing in place.
- to use the proper hardware fittings according to the construction of the wall.

For more specific information, please refer to the WARNINGS section at the end of the catalogue.


**OPTIONAL COVER CAP INSERTING** 

- For details refer to "LIBRA H11 ACCESSORIES".




#### DRILLING PLAN WITHOUT COVER CAP






Back panel




#### DRILLING PLAN WITH COVER CAP




#### Side panel and service gap




Back panel



## LIBRA H11 SCREW FIXING





NOTE: for technical details about wall plates please refer to the related sections "LIBRA WALL PLATES" on page 12.65.




20102020GR

13

15


# LIBRA H11 SCREW FIXING ACCESSORIES




Back to table of contents



# LIBRA H11 WITH PRE-MOUNTED BUSHES AND SCREWS






NOTE: for technical details about wall plates please refer to the related sections "LIBRA WALL  $\mbox{PLATES}".$ 





# LIBRA H11 COVER CAP

#### INSTALLATION



































Suitable for base units with LIBRA H6, H7, H11.



Suitable for wall cabinet units with LIBRA H1, H2, H3, H4.

()

= 100 pcs.

ST

S

63450060<mark>ZN</mark>

# LIBRA WP6 FOR SERVICE GAP 20 mm MINIMUM

R Certificates available on request. 10,8 38 6,5 UNI 10768 1150 N 1150 N Ø  $\oslash$ 51,8 WP6 - L WP6 - R 5,5 2 15 47 100 (F Certificates available on request. LIBRA WP7 13,8 33 2 31 ω B -----Position B 11 6 90,4 5,5

45

Position A



Suitable for wall cabinet units with LIBRA H1, H2, H3, H4.

Ð = 100 pcs.



Position A: standard application for regular walls. Position B: specific application for wall tiles thicker than 8mm.

12


20,5 46


44

#### Back to table of contents


5,8

HANGERS





Ø12



NOTE: The length of the wall bar is 2400 mm. The use of this article is possible only with a service gap of 24 mm.




Back to table of contents


# LIBRA COVER CAPS




# LIBRA CC1 COVER CAP




## LIBRA CC2 COVER CAP






# LIBRA CC4 COVER CAP



# LIBRA CC5 COVER CAP



# LIBRA BS APPLICATIONS

#### BENEFITS OF LIBRA BS HANGING SYSTEM:

- Vertical and in-depth adjustments, with integrated locking of the cabinet, can be easily and smoothly carried out from the inside.

- The hanging system is never interfering with the slides for drawers thanks to the slim side bracket wings.
- Absolutely no mills, nor grooves required on the side panels.


In the current absence of a unifying European norm which sets the standards for testing procedures aimed at defining capacity loadings of hanging systems conceived for suspended base units, we Italiana Ferramenta have simulated some of the most critical scenarios. The following simulations are meant to give our customers valid reference points concerning cabinet dimensions, weights, recommended loading capacity even when loaded drawers are opened. The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled.

The customer must ensure that the wall is of suitable quality and structure.

- Other important factors to be taken into consideration are determined by:
- the type of side panel, the actual thickness and the material used.
- the type and dimensions of the screws used.
- the actual positioning, depth and width of the groove milled for the back side installation.
- the capacity loading of the drawer slides used as well as the actual construction of the drawer.


We always recommend to test a complete cabinet.

For cases which differ from the ones reported, please contact us.






The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled.



Libra BS with 2 intermediate hooks



The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled.



Libra BS with 1 intermediate hook




12

The reported data, empirically obtained, exclusively refer to the constructions and examples shown, correctly positioned and assembled.

Back to table of contents

# HANGERS

The hanging system is never interfering with the slides for drawers thanks to the slim side bracket wings.




Easy access to the adjustments





The slim side bracket makes the use of tools very easy and comfortable as there is plenty of space between the side and the allen wrench.



By adding intermediate hooks to Libra BS, the capacity loading is more evenly distributed, thus sensibly reducing the stress intensity level on the wall.








# LIBRA BS




PATENTED












APPLICATION OF THE LIBRA BASE SYSTEM TO THE SUSPENDED BASE CABINET



WALL BAR INSTALLATION AND CABINET HANGING



Back to table of contents



S5 mm allen wrench


Vertical adjustment to be carried out through both side hangers. The intermediate hooks consequently follow the vertical adjustment carried out through the side hangers.

## ANTI-TURNOVER SYSTEM AND INCLINATION ADJUSTMENT

In-depth adjustment to be carried out progressively through side hangers and intermediate hooks.

SIDE HANGERS

# INTERMEDIATE HOOKS



Combi slot for S6 mm allen wrench and both cross PZ2 or PH2 and blade screwdriver 1,6 x 10 mm.


Inclination adjustment if required

- For details refer to section " LIBRA BS LEVELLER"


# HANGERS


#### SIDE PANEL 15 - 16 MM THICK


SIDE PANEL 18 - 19 MM THICK




## SIDE PANEL DRILLING AND MILLING FOR VARIOUS BACK PANEL DIMENSIONS








## LIBRA BS WITH END ELEMENTS PRE-MOUNTED



NOTE:


- LIBRA BS is supplied in carton box including 1 piece plus 1 LIBRA BS WALL BAR.

- LIBRA BS WALL BAR is supplied 10 mm shorter than LIBRA BS for lateral adjustment.




If <u>L</u> in mm is equal to a whole number use following code system:

L in mm minus 66 (which includes plus 0,5 tolerance)



If <u>L</u> in mm is equal to a number ending with a plus 0,5 mm use following code system:




Z = without intermediate hook A = with 1 intermediate hook B = with 2 intermediate hooks C = with 3 intermediate hooks SUGGESTED COMBINATIONS:

SUGGESTED COMBINATIONS:		
CABINET WIDTH (mm)	INTERMEDIATE HOOK	
450	-	
500	-	
600	1	
700	1	
800	2	
900	2	
1000	2	
1100	2	
1200	3	
1500	3	

HANGERS

WALL BAR DETAIL




32

32


15,5


## LIBRA BS LEVELLER




recommended fixing insert nuts M6 x 10-13 mm Combi slot for S6 mm allen wrench and both cross PZ2 or PH2 and blade screwdriver 1,6 x 10 mm. Fecommended fixing countersunk head screws M6 x 16 mm

ANTI-TURNOVER SYSTEM AND INCLINATION ADJUSTMENT







SIDE HANGERS



INTERMEDIATE HOOKS



The self-inserting anti-turnover device is carried out after 6 mm of in-depth adjustment.




Inclination adjustment if required

# HANGERS

## SIDE PANEL 15 - 16 MM THICK

SIDE PANEL 18 - 19 MM THICK




BACK PANEL WOOD THICKNESS 4 MM


PLACED IN THE LOWER SLOT


## SIDE PANEL DRILLING AND MILLING FOR VARIOUS BACK PANEL DIMENSIONS

BACK PANEL WOOD THICKNESS 4 MM PLACED IN THE HIGHER SLOT











l 4 min.


15,5

<u> 38 - </u>42




BACK PANEL WOOD THICKNESS 8 MM






According to customer's needs use: 6593000000 - Leveller 12 mm adjustment 6593200000 - Leveller 25 mm adjustment




According to customer's needs use: **6593000000** - Leveller 12 mm adjustment

Only in case of service gap 42 mm min: **6593200000** - Leveller 25 mm adjustment




According to customer's needs use: 6593000000 - Leveller 12 mm adjustment 6593200000 - Leveller 25 mm adjustment


























# LIBRA BS LEVELLER ACCESSORY




= Ø 10 mm	+ 🃎
EP	() = 5000 pcs.
23002020AB	

# LIBRA BS LEVELLER FIXING ACCESSORIES







# **ANTI-TIP BRACKETS**








SH7

SH1




# SH1 ANTI-TIP BRACKET





## INSTALLATION UNDER THE CABINET TOP


INSTALLATION ON THE WALL LOCKING





## DRILLING PLAN FOR SH1 FIXED UNDER THE CABINET TOP

## SIDE PANEL AND SERVICE GAP

BACK PANEL

















## SH1 FIXING ACCESSORY









# SH7 ANTI-TIP BRACKET





INSTALLATION UNDER THE CABINET TOP








recommended fixing countersunk head wood screws Ø3,5 mm

INSTALLATION ON THE WALL LOCKING





## DRILLING PLAN FOR SH7


## SIDE PANEL

BACK PANEL

<u>15 min.</u>

















# SH WALL PLATE





ST	🛞 = 200 pcs.
63423200 <mark>ZN</mark>	

## WALL PLATE POSITION WITH SH1 AND SH7




## LIKU




**INSTALLATION: LIKU AND LEVELLER** Ø 14 H. 52 INSTALLATION

recommended fixing pan head wood screws Ø 4x60 mm




VERTICAL ADJUSTMENT - 15 mm



Back to table of contents

WALL PLATE FIXING AND LATERAL ADJUSTMENT - 6 mm




interzum award: intelligent material & design 2011



250 Kg per piece

25 mm min.

#### INSTALLATION AND FURTHER LATERAL ADJUSTMENT - 3 mm




For more specific information, please refer to the WARNINGS section at the end of the catalogue.


3

#### **IN-DEPTH ADJUSTMENT - 13 mm** AND ANTI-TURNOVER SYSTEM

It is the responsibility of the customer:




## INCLINATION ADJUSTMENT




12.87 🗭


# HANGERS



**A** = Distance from top edge




# LEVELLER Ø 14 H 52 mm




- For details refer to section " <code>LEVELLER</code> Ø 14"

## Back to table of contents






# LIKU ACCESSORY





# LIKU FIXING ACCESSORY




## **DRILL BIT FOR LIKU**














# DRILL BIT FOR LEVELLER Ø 14

















#### KAIMAN

The strength and the ability to withstand the stresses of KAIMAN assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which KAIMAN is intended to be fixed. Italiana Ferramenta may not guarantee the strength of KAIMAN in the absence of adequacy of the load-bearing wall.

#### KAIMAN MAXI

The strength and the ability to withstand the stresses of KAIMAN MAXI assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which KAIMAN MAXI is intended to be fixed. Italiana Ferramenta may not guarantee the strength of KAIMAN MAXI in the absence of adequacy of the load-bearing wall.

#### KALABRONE

The strength and the ability to withstand the stresses of KALABRONE assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which KALABRONE is intended to be fixed. Italiana Ferramenta may not guarantee the strength of KALABRONE in the absence of adequacy of the load-bearing wall.

#### **KALABRONE MAXI**

The strength and the ability to withstand the stresses of KALABRONE MAXI assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which KALABRONE MAXI is intended to be fixed. Italiana Ferramenta may not guarantee the strength of KALABRONE MAXI in the absence of adequacy of the load-bearing wall.

### **KALABRONE MINI**

The strength and the ability to withstand the stresses of KALABRONE MINI assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which KALABRONE MINI is intended to be fixed. Italiana Ferramenta may not guarantee the strength of KALABRONE MINI in the absence of adequacy of the load-bearing wall.

#### COBRONE

The strength and the ability to withstand the stresses of COBRONE assumes a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which COBRONE is intended to be fixed. Italiana Ferramenta may not guarantee the strength of COBRONE in the absence of adequacy of the load-bearing wall.

#### **TRIADE MINI**

The strength and the ability to withstand the stresses of TRIADE MINI assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE MINI is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE MINI in the absence of adequacy of the load-bearing wall.

#### TRIADE MINI AND BRACKET

The strength and the ability to withstand the stresses of TRIADE MINI AND BRACKET assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE MINI AND BRACKET is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE MINI AND BRACKET in the absence of adequacy of the load-bearing wall.

#### TRIADE

The strength and the ability to withstand the stresses of TRIADE assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE in the absence of adequacy of the load-bearing wall.

#### TRIADE AND BRACKET

The strength and the ability to withstand the stresses of TRIADE AND BRACKET assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE AND BRACKET is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE AND BRACKET in the absence of adequacy of the load-bearing wall.

#### **TRIADE MAXI**

The strength and the ability to withstand the stresses of TRIADE MAXI assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE MAXI is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE MAXI in the absence of adequacy of the load-bearing wall.

#### TRIADE MAXI AND BRACKET

The strength and the ability to withstand the stresses of TRIADE MAXI AND BRACKET assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE MAXI AND BRACKET is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE MAXI AND BRACKET in the absence of adequacy of the load-bearing wall.

### TRIADE XXL

The strength and the ability to withstand the stresses of TRIADE XXL assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE XXL is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE XXL in the absence of adequacy of the load-bearing wall.

#### TRIADE XXL AND BRACKET

The strength and the ability to withstand the stresses of TRIADE XXL AND BRACKET assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which TRIADE XXL AND BRACKET is intended to be fixed. Italiana Ferramenta may not guarantee the strength of TRIADE XXL AND BRACKET in the absence of adequacy of the load-bearing wall.

#### APC1

The strength and the ability to withstand the stresses of APC1 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which APC1 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of APC1 in the absence of adequacy of the load-bearing wall.

#### APC3

The strength and the ability to withstand the stresses of APC3 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which APC3 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of APC3 in the absence of adequacy of the load-bearing wall.

#### APC4

The strength and the ability to withstand the stresses of APC4 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which APC1 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of APC4 in the absence of adequacy of the load-bearing wall.

#### APC6

The strength and the ability to withstand the stresses of APC6 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which APC1 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of APC6 in the absence of adequacy of the load-bearing wall.

#### LIBRA H1

The strength and the ability to withstand the stresses of LIBRA H1 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H1 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H1 in the absence of adequacy of the load-bearing wall.

#### LIBRA H2

The strength and the ability to withstand the stresses of LIBRA H2 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H2 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H2 in the absence of adequacy of the load-bearing wall.

#### LIBRA H3

The strength and the ability to withstand the stresses of LIBRA H3 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H3 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H3 in the absence of adequacy of the load-bearing wall.

#### LIBRA H4

The strength and the ability to withstand the stresses of LIBRA H4 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H4 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H4 in the absence of adequacy of the load-bearing wall.

#### LIBRA H6

The strength and the ability to withstand the stresses of LIBRA H6 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H6 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H6 in the absence of adequacy of the load-bearing wall.

#### LIBRA CH

The strength and the ability to withstand the stresses of LIBRA CH assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA CH is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA CH in the absence of adequacy of the load-bearing wall.

#### LIBRA H7

The strength and the ability to withstand the stresses of LIBRA H7 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H7 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H7 in the absence of adequacy of the load-bearing wall.

#### LIBRA H11

The strength and the ability to withstand the stresses of LIBRA H11 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA H11 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA H11 in the absence of adequacy of the load-bearing wall.

#### LIBRA BS

The strength and the ability to withstand the stresses of LIBRA BS assumes a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIBRA BS is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIBRA BS in the absence of adequacy of the load-bearing wall.

#### LIKU

The strength and the ability to withstand the stresses of LIKU assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which LIKU is intended to be fixed. Italiana Ferramenta may not guarantee the strength of LIKU in the absence of adequacy of the load-bearing wall.

#### SH1 ANTI-TIP BRACKET

The strength and the ability to withstand the stresses of SH1 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which SH1 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of SH1 in the absence of adequacy of the load-bearing wall.

#### SH7 ANTI-TIP BRACKET

The strength and the ability to withstand the stresses of SH7 assume a good state of the load-bearing wall and the plaster possibly superimposed therein. It is the responsibility of the customer to verify that the wall is in condition and of sufficient quality to support the fixing and that the tools used are compatible with the surface on which SH7 is intended to be fixed. Italiana Ferramenta may not guarantee the strength of SH7 in the absence of adequacy of the load-bearing wall.

**(F)** 12.94